RADONIX PC-Pro

Connection between RadonixPC-Pro and Delta VFD-B

In Delta VFD-B put <u>SW1</u> in <u>Sink</u> Mode

RadonixPC-Pro Pins	Description	VFD-B Pins
AO1/AO2	6 Pin Connector	AVI
GND	6 Pin Connector	ACM
Onn	OutPort 8-Pins Connectors	FWD
Onn	OutPort 8-Pins Connectors	REV
GND	Power Ground	DCM